




## **135-Degree Inside Corner – Bay Window Units:**

### **Measuring Instructions:**

**First**, you will need to remove the endcaps and front panel of the heaters that are meeting in the bay window corners.

It is best to measure from where the front plates will meet. Usually located 2.5" - 3" in front of the back plate.

**Note:** Bay window corners demand the greatest accuracy as there is little "play" in getting more span from these accessories.



### **Installation instructions:**

\*Install panels on the wall.

\*For attaching the corner piece, start at the bottom of the panel and place the angled piece of the shaft underneath where the panels meet in the corner.

\*Next, move the inside corner piece upward to secure the clip (located on the right side of the corner piece) over the top of the panel.

## **135-Degree Outside Corner – Bay Window Units:**

Measure from the far end of the application to the point where two walls meet at the outside corner. Note: There is no need for deducting 3" from the measurement since the outside corner piece attaches differently than the inside corner piece. The outside corner piece will extend beyond where the walls meet and clip to the end of the panels.

